Digital Clock



The digital clock displays the time with the ignition switch in any position.
To set the clock:

1. Press and hold the H button until the hour advances to the desired hour.

2. Press and hold the M button until the numbers advance to the desired minutes.

You can use R to quickly set the time to the nearest hour. If the displayed time is before the half hour, pressing R sets the clock back to the previous hour. If the displayed time is after the half hour, pressing R sets the clock forward to the beginning of the next hour.
For example:

- 1:06 would RESET to 1:00.
- 1:52 would RESET to 2:00.

Console Compartment, Coin Box

Console Compartment



To open the console compartment, pull up on the lower lever and lift the lid.

To close, lower the lid and push it down until it latches.



You can put small items in the tray located in the console compartment lid. To use the tray, pull up on the upper lever and lift up the armrest pad.

Coin Box



The coin box is located under the air vent. To open the coin box, pull the bottom edge. Close it with a firm push.